

PL1

Binary Distillation

Group 4
 Jake Proctor, Milos Markovic,
 Courteney Fabbri, Erica Caruso
 Chemical Engineering Lab I
 31 October 2019

UIC UNIVERSITY OF ILLINOIS
AT CHICAGO

1

PL1

Introduction

- The main purpose of this lab was to study the separation process of a binary mixture (EtOH and H₂O)
- Separation method used was batch distillation
- Performed distillation with both total reflux and constant reflux ratios
- This lab also served to study the accuracy of the McCabe-Thiele method for analyzing a binary distillation^{PL2}

UIC UNIVERSITY OF ILLINOIS
AT CHICAGO

2

PL2

Theory

- McCabe-Thiele Method Assumptions:
 - Each stage is at equilibrium
 - 100% efficiency of the stages
- Operating equations

$$\text{Top: } y = \frac{L}{V}x + \left(1 - \frac{L}{V}\right)x_D$$

$$\text{Bottom: } y = \frac{L}{V}x - \left(\frac{L}{V} - 1\right)x_B$$
- Total reflux $L = V$
 - Calculate efficiency of column from:

$$n + 1 = \frac{\log\left(\frac{x_{D50}}{x_{D20}}\right) \left(\frac{x_{D20}}{x_{B50}}\right)}{\log\left(\frac{x_{D50}}{x_{B50}}\right)}$$
 AND $E = \frac{\text{number of theoretical plates}}{\text{number of actual plates}} \times 100\%$
- Constant reflux ratios
 - Use McCabe-Thiele analysis to determine efficiency

UIC UNIVERSITY OF ILLINOIS
AT CHICAGO

3

PL2

Apparatus

- Main Equipment
 - Column
 - Reboiler
 - Condenser
 - Trays
 - Manometer
 - Heater
 - Valves^{*}
 - Heat exchanger
 - Reflux valve
 - Decanter
 - Top product receiver
 - Bottom product receiver
 - Cooling water flowmeter

^{*} Note there are many valves in this experiment




UIC UNIVERSITY OF ILLINOIS
AT CHICAGO

4

Slide 1

DL1 98/100
Donglin Li, 11/2/2019

Slide 2

DL2 Font sizes could be bigger.
Donglin Li, 11/2/2019

DL3 -1
Donglin Li, 11/2/2019

Slide 3

DL4 Type instead of pictures.
Donglin Li, 11/2/2019

DL8 -1
Donglin Li, 11/2/2019

Material & Supplies

• Material list

- Ethanol
- Water
- Large graduated cylinder
- Measuring cylinder
- Timer
- Bottle
- Refractometer
- Test tubes
- Computer
- Armfield console
- Pipettes
- Tap water
- Water bath and rack
- Funnel



UIC UNIVERSITY OF ILLINOIS
AT CHICAGO

5

Procedure

• Prelab Steps

1. Familiarize team with equipment
2. Calculate volume for EtOH and H₂O for 10 wt% solution

• Lab Day Steps

1. Make 10 wt% EtOH and H₂O solution
2. Load in boiler and heat until constant temperatures on computer
3. Create calibration curve for refractometer with 10 wt% increment composition mixtures of EtOH and H₂O

Part A

1. Set column to total reflux and collect top and bottom samples for refractometer indexing, as well as taking boil-up rate and pressure drop of column at various boiler power settings

Part B

1. Set column to constant reflux ratio and repeat Part A step 1 (no need to take pressure drop)
2. Repeat for various reflux ratios

UIC UNIVERSITY OF ILLINOIS
AT CHICAGO

6

Experimental Challenges

• Difficulties

- Understanding the operation of the column

• Things to watch out for during the experiment

- Not to open valves too fast and overflow test tubes while collecting
- Make sure the cooling water is on and at 3000 cc/min
- Turn valves the correct direction

• Lessons Learned

- Best to have one person taking data, one person performing refractometer indexing, and two people operating column
- Check calculations for 10 wt% solution of EtOH and H₂O

UIC UNIVERSITY OF ILLINOIS
AT CHICAGO

7

Safety

- Wear gloves and goggles at all times
- Boiler and samples collected are HOT – use caution and heat gloves
- Be careful not to overflow hot samples while collecting

UIC UNIVERSITY OF ILLINOIS
AT CHICAGO

8

Slide 5

DL6 **Good.**
Donglin Li, 11/2/2019

Slide 6

DL7 **Good.**
Donglin Li, 11/2/2019