

# ***Membrane Air Separation***

*Pre-Lab Plan*  
*Unit Operations Lab*   
*November 14<sup>th</sup>, 2019*

*Group 1, Thursday, PM section*  
*Alexis Miranda*  
*Dulce Colindres*  
*Kathya Chavez*

## 1. Experimental Objective

This experiment revolves around the separation of air into oxygen and nitrogen components using a membrane separation apparatus. The goal of this lab is to evaluate the overall transfer coefficients  $K_{O_2}$  and  $K_{N_2}$ , separation coefficient  $\alpha_{AB}$ , the experimental separation factors,  $\alpha'_{AB}$ ,  $\alpha''_{AB}$ , and the  $O_2$  and  $N_2$  recoveries, all as functions of operating pressures measured in lab.

## 2. Experimental

The figure below shows the apparatus used for the membrane air separator. Compressed air from a tank, enters the system with various valves and meters for testing the quality of oxygen compared to air.

### 2.1 Apparatus



Figure 1: Apparatus for Membrane Air Separation

Table 1: Apparatus Components

| Component                                    | Description                            |
|----------------------------------------------|----------------------------------------|
| 1. Air Cylinder                              | Pressurized air for testing            |
| 2. Power source                              | System Power source                    |
| 3. Two Prism <sup>TM</sup> separator modules | Columns with semipermeable membranes   |
| 4. Pressure Sensor                           | Reads pressure flow                    |
| 5. Needle Valve                              | Control Flow                           |
| 6. 2 flow meters                             | Sensor to read quality                 |
| 7. 2 O <sub>2</sub> sensor                   | Reads oxygen quality                   |
| 8. 2 Exit tubes                              | Allows air to flow out of the system   |
| 9. 2 filters                                 | Allows Air sensors to read air quality |

## 2.2 Materials and Supplies

Table 2: Materials and Supplies

| Material / Supplies | Description                                                                  |
|---------------------|------------------------------------------------------------------------------|
| Batteries           | To power the oxygen analyzers                                                |
| Compressed Air      | Compressed Air provided from tank next to apparatus                          |
| Oxygen Analyzers    | Provide recovery rate, shows when system at steady state, battery powered    |
| Mass Flow Meters    | To provide flow rate data, powered through power strip attached to apparatus |
| Pressure Gauge      | Provides pressure reading in system, attached to apparatus                   |

## 2.3 Experimental Plan

- Set the outlet pressure to 140psig by opening the valve on the high pressure air cylinder and adjusting the cylinder regulator.
- Turn on oxygen analyzers and allow time for the readings to reach steady state. Calibrate if necessary.
- Make sure the mass flow meters are plugged into the power strip along with the pressure transducer display.
- Parallel Configuration:
  - Point valves into the correct directions:
    - VA- Left, VB-up to sample and down to vent, VC-down, VD- up to sample and down to vent.
  - 5 runs will be conducted at 20psig and varying flowrates, 4 runs will be conducted at 40psig with varying flowrates, and 4 runs will be conducted at 80psig with varying flowrates.
  - The runs end when the flowrates and oxygen levels are constant
  - Changing flowrate may change pressure so readjust pressure as needed.

- e. Record operating pressure, tube side flowrate, tube side oxygen level, shell side flowrate, and shell side oxygen level
5. Series Configuration:
- a. Point valves in correct directions:
    - i. VA-right, VB-up to sample and down to vent, VC- up, VD- up to sample and down to vent.
    - ii. Run and collect data for 15 runs, similar to parallel configuration

### Independent & Dependent Variables

|                    |
|--------------------|
| <b>Dependent</b>   |
| Oxygen Levels      |
| <b>Independent</b> |
| Pressure           |
| Flowrate           |

### Data Collection

| Operating Tube Side |                 |                   |                            | Module 1                     | Module2                      | Module 1                  | Module 2                     |
|---------------------|-----------------|-------------------|----------------------------|------------------------------|------------------------------|---------------------------|------------------------------|
| Run #               | Pressure (psig) | Flowrate (mL/min) | Tube side oxygen level (%) | Shell side flowrate (mL/min) | Shell side flowrate (mL/min) | Shell side oxygen level % | Shell side flowrate (mL/min) |
| 1                   | 20              | 500               |                            |                              |                              |                           |                              |
| 2                   | 20              | 1000              |                            |                              |                              |                           |                              |
| 3                   | 20              | 2000              |                            |                              |                              |                           |                              |
| 4                   | 20              | 4000              |                            |                              |                              |                           |                              |
| 5                   | 20              | 8000              |                            |                              |                              |                           |                              |
| 6                   | 40              | 1000              |                            |                              |                              |                           |                              |
| 7                   | 40              | 2000              |                            |                              |                              |                           |                              |
| 8                   | 40              | 4000              |                            |                              |                              |                           |                              |
| 9                   | 40              | 8000              |                            |                              |                              |                           |                              |
| 10                  | 80              | 1000              |                            |                              |                              |                           |                              |
| 11                  | 80              | 2000              |                            |                              |                              |                           |                              |
| 12                  | 80              | 4000              |                            |                              |                              |                           |                              |
| 13                  | 80              | 8000              |                            |                              |                              |                           |                              |

This table will be filled out during exSperiment, thus presented in final report.

## Project Safety Evaluation

Project Title: Membrane Air Separation

Date: 11/14/2019

|                                                                                                          |                     |                                                                                                          |
|----------------------------------------------------------------------------------------------------------|---------------------|----------------------------------------------------------------------------------------------------------|
|                                                                                                          | Yes/No              |                                                                                                          |
| Potential electrical hazards?                                                                            | Yes                 | Power strip next to apparatus powering machinery which can cause electrocution.                          |
| Potential mechanical hazards?                                                                            | Yes                 | Pipes with varying pressure. Pressure buildup in pipes can cause them to burst                           |
| Potential pressure hazards?                                                                              | Yes                 | Compressed Air tank is used. All safety precautions when using compressed fluid in tanks should be taken |
| Potential temperature hazards?                                                                           | No                  | Experiment will be conducted at standard room temperature.                                               |
| Hazardous/toxic chemicals involved?                                                                      | No                  | Compressed air in closed system would be used but not any toxic chemicals.                               |
| Gloves required?                                                                                         | No                  | Always recommended but not required for this lab                                                         |
| MSDS reviewed by all team members?                                                                       | Yes                 | MSDS reviewed by all team members                                                                        |
| <b>Process Parameters</b>                                                                                | <b>Max Expected</b> | <b>List location and possible hazards and precautions</b>                                                |
| Temperature (°C)                                                                                         | 25°C                | Room Temperature                                                                                         |
| Pressure (psia)                                                                                          | 140 psig            | Lab will be conducted at varying pressures, with 140 psig chosen as our max                              |
| <b>Safety Controls</b>                                                                                   | <b>yes/no</b>       | <b>If yes, Provide description</b>                                                                       |
| Wearing proper PPE, being careful when inserting particles, wear glasses, gloves, face masks if possible | Yes                 | Wear goggles                                                                                             |

|  |  |  |
|--|--|--|
|  |  |  |
|--|--|--|

*I have read relevant background material for the Unit Operations Laboratory entitled: "Membrane Air Separation" and understand the hazards associated with conducting this experiment. I have planned out my experimental work in accordance to standards and acceptable safety practices and will conduct all of my experimental work in a careful and safe manner. I will also be aware of my surroundings, my group members, and other lab students, and will look out for their safety as well.*

Alexis Miranda

*Signature of team member*

11/14/19

*Date*

Dulce Colindres

*Signature of team member*

11/14/19

*Date*

Kathya Chavez

*Signature of team member*

11/14/19

*Date*